

Singing and dancing Father Christmas

Highlights

- Operation with 3x AA batteries (not included)
- Switching on and off with a simple slide switch
- Button for Activate the figure
- Dances
 humorously to lively music

Scope of delivery

- Singing and dancing Father Christmas
- · Operating instructions


Warranty period

2 year

Discover the festive magic with the singing and dancing Father Christmas! At approx. 30 cm tall, this charming little chap is just the thing to bring joy and cheer into your home.

Father Christmas performs a humorous dance routine to lively music. His melodies spread festive cheer and invite you to sing and dance along. Simply press the button and Father Christmas begins his song and cheerful dance performance.

Father Christmas is powered by 3 AA batteries, which ensure a long operating time.



Specifications:

- Height: approx. 30 cm
- With on/off switch
- · With humorous dance number
- · With lively music
- Button to activate the figure
- Material: plastic and fabric
- Operated with 3× AA batteries (not included!)

Dimensions:

- Product (W×H×D): 243×290×102 mmPackaging (W×H×D): 191x241x142 mm
- Packaging (W×H×D): 191x241x142 mm
 Net/gross weight: 320 g / 430 g







Schuss Home Electronic GmbH, Scheringgasse 3, 1140 Wien, 7015 +43 (1) 970 21 - 0